

Tree protection - 25106-TPP-07

Location of trees, categorisation & protection/management proposals

Hamble Point Marina, Saltmakers House, School Lane, Southampton, Hampshire SO31 4NB

Scale @ A1 1:250

0510152025 m

Provided drawings

Topo: (16th OCT 2025) 726881 - Hamble Point Marina - DWG04 - Site Plan GEOREFTOPO - EDIT

Layout: (21st JUL 2026) 726881 - Hamble Point Marina - DWG04A - Site Plan 210726

Tree types

T = Tree, G = Group, H = Hedge, W = Woodland, AW = Ancient woodland, V = Veteran

Application boundary

BS category C Trees of low quality

Trees to be removed

Proposed layout

Protective barrier/fencing

Construction exclusion zone

Root protection area (RPA) boundaries for category C trees

Tree	Species	Category	Nominal RPA radius (m)	Tree works
T1	Fir	C	1.2	
T2	Fir	C	0.9	
T3	Fir	C	0.9	
T4	Birch	C	2.7	
T5	Birch	C	2.1	
T6	Birch	C	2.4	
T7	Sea buckthorn	C	4.8	Fell for development
T8	Sea buckthorn	C	4.2	Fell for development
H9	Pyracantha	C	0.6	
T10	Smoke tree	C	2.1	

All retained trees & hedges
Carry out safety check and lift over site to 3-4 m as necessary

How to use this plan

More detailed guidance on each Site Guidance Note (SGN) can be found in a printed hard copy compilation of all the SGNs, **Manual for Managing Trees On Development Sites** version 3.0, issued to the Site Manager at the pre-commencement site meeting (Note: This should be retained on site throughout the duration of works). Additionally, an electronic pdf compilation of all the SGNs, was submitted with this drawing to the local planning authority and the client. Alternatively, a pdf of each SGN can be downloaded by:

1. clicking the image links in the electronic pdf version of this plan;

2. holding a mobile phone QR (Quick Response) code reader over the QR code in the paper version of this plan; or;

3. visiting our website at <https://www.barrelltreecare.co.uk/resources/technical->

b

barrell

TREE CONSULTANCY

Permission is granted to scale from this drawing for Local Authority Planning Approval purposes relating to tree protection measures only. Where applicable this drawing is to be read in conjunction with the arboricultural report.

www.barrelltreecare.co.uk © Barrell Tree Consultancy

SGN 1

Monitoring tree protection

Always:

✓ have a pre-commencement meeting with the tree consultant before development starts

✓ use the tree consultant to regularly check that protection remains fit for purpose

✓ use the tree consultant to supervise work in RPAs

✓ keep a written record of supervision

SGN 2

Fencing protected trees

Always:

✓ install protection before development starts

✓ make sure protection is fit for purpose, i.e. it prevents damage to trees and soil

✓ keep protection in place until there is no risk to trees

✓ get written permission to move or remove any protection

SGN 4

Pollution control

Always:

✓ keep toxic products away from RPAs

SGN 11

Installing services in RPAs

Always:

✓ use the tree consultant to supervise work in RPAs

✓ select the least damaging option when installing services, so prioritise trenchless, over broken trench over continuous trench

✓ hand-dig trenches if trenchless is not feasible

SGN 12

Landscaping in RPAs

Always:

✓ use the tree consultant to supervise work in RPAs

✓ avoid raising ground levels within 1m of the trunks of retained trees

25106-TPP-07 23-Jul-2026 by Kierstin Hall