


11 Installation

11 - 1 Installation Method

11


VAM150FC



Symbols
 OA = Fresh outdoor air
 EA = Exhaust air
 SA = Supply air to room
 RA = Return air from room

3D099263

VAM250FC



Symbols
 OA = Fresh outdoor air
 EA = Exhaust air
 SA = Supply air to room
 RA = Return air from room

3D099264