

EXISTING DRAINAGE RUN

NEW FUMH02
ON EXISTING
RUN

---> = SURFACE WATER DRAINAGE
->- - - = Foul DRAINAGE

