Bat boxes B1 and B2

Two integrated bat boxes in the front wall of the two-storey extension.
Install high on the wall, ideally at least 2.5 m above ground, with clear access.
Keep entrances clear of direct lighting.



FRONT ELEVATION



SIDE ELEVATION



REAR ELEVATION

Swift boxes S1 and S2

Two nest boxes below the rear eaves, built in or fixed to the external wall.
Install at least 5 m above ground, in shade and away from windows.
Keep the approach clear for flying birds.

Biodiversity enhancements

Box positions follow Figure 6 of the Hampshire Ecological Services Bat Emergence Survey Report dated 30 October 2026.
Coloured symbols show the proposed locations.

CLIENT:	GABRIEL JANKO
PROJECT:	16 Grange Road SO302FB
TITLE:	RENDERED ELEVATIONS
DATE: 08-11-2026	DRAWN BY: M L
SCALE @ A3: 1:100	CHECKED BY: M L
PROJECT NO: 0125	DRAWING NO: 7
REV NO:	